



PREMIUM AFTERMARKET WIND DEFLECTORS

Mercedes-Benz R129 wind deflector fitting instructions



For our installation video please visit: <https://youtu.be/YmDvqMzowio>
Copy the link in your browser and you will be directed to the video.

What's in the box

- 1 x wind deflector
- 2 x brackets
- 2 x bolts
- 2 x plastic caps
- 1 x installation manual

Product No: 23.04.01.01



Product No: 23.04.01.04



Product No: 23.04.01.03



Product No: 23.04.02.11





PREMIUM AFTERMARKET WIND DEFLECTORS

STEP 1

Attach the brackets to the wind deflector using the supplied bolts, washer and caps.



STEP 2

Open the top and fold the roll bar forward using the switch in your center console.





PREMIUM AFTERMARKET WIND DEFLECTORS



STEP 3

Step out of the car and fold the seats forward.





PREMIUM AFTERMARKET WIND DEFLECTORS

STEP 4

Place the wind deflector in the car and attach both Velcro straps to the roll bar.





PREMIUM AFTERMARKET WIND DEFLECTORS

STEP 5

Push the brackets against the roll bar.





PREMIUM AFTERMARKET WIND DEFLECTORS

STEP 6

Lower the roll bar and fold the top part of the wind deflector upright.





PREMIUM AFTERMARKET WIND DEFLECTORS

STEP 6

Go out for a drive and enjoy your APERTA wind deflector!

